

## Dräger Flow Check Air Flow Indication

The Dräger Flow Check air current indicator produces a harmless cloud of smoke that floats freely and easily, because it has the same density as ambient air. Consequently, slight air currents become visible to easily identify leaks and test the integrity of air-tight systems.



ST 466-08

## Benefits

---

### Better room temperature and air quality

For the optimal setting of air conditioning systems, air flows have to be located accurately and precisely. With the Flow Check air flow indicator even slightest air movements are made visible to the eye so that their origin, course and speed can be easily detected in order to ensure the functionality of ventilation systems and chimneys. The device produces a cloud of smoke, that floats freely and easily, because it has the same density as ambient air.

---

### Harmless smoke

The Dräger Flow Check consists of one device for the smoke production and an ampoule containing smoke-generating fluid (an alcohol mixture that is harmless to the environment). A small heating element in the head of the instrument heats the fluid, which condenses on contact with the ambient air.


---

### Easy to use

The ergonomically top-designed, hand-held instrument is of low weight and offers an optimum ease of operation. Individual little fog clouds are generated at the touch of a button. For a continuous fog generation simply press the button constantly or lock it.

## Accessories

---



### Dräger Flow-Check Ampoules

Part Number 64 00 812

## Technical Data

Operating Temperature	5 °C to 40 °C
Smoke Time per Ampoule	approx. 3 min
Operating Time per Battery Charge	approx. 20 min
Ni-Cd rechargeable Battery	7.2 V; 1.4 Ah
Charging current	700 mA
Dimensions	approx. 300 mm x 200 mm x 70 mm
Weight	approx. 500 g

## Ordering Information

<b>Dräger Flow Check</b>	
Air flow indicator with one pack of ampoules, battery pack, packed in plastic case	64 00 761
<b>Accessories</b>	
Flow Check ampoules (3 ampoules and 1 nozzle)	64 00 812
Battery charger, 4.8 V - 12 V / 600 mA	83 16 993
Adapter cable for in-car recharging	64 00 803
Battery pack	64 00 817

## Notes

### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53–55  
23558 Lübeck, Germany  
[www.draeger.com](http://www.draeger.com)

### Manufacturer:

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck, Germany

### REGION EUROPE CENTRAL AND EUROPE NORTH

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck, Germany  
Tel +49 451 882 0  
Fax +49 451 882 2080  
[info@draeger.com](mailto:info@draeger.com)

### REGION EUROPE SOUTH

Dräger Safety France SAS  
25, rue Georges Besse  
92182 Antony Cedex  
Tel +33 1 46 11 56 00  
Fax +33 1 40 96 97 20  
[europe.south@draeger.com](mailto:europe.south@draeger.com)

### REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA  
Branch Office  
P.O. Box 505108  
Dubai, United Arab Emirates  
Tel +971 4 4294 600  
Fax +971 4 4294 699  
[contactuae@draeger.com](mailto:contactuae@draeger.com)

### REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd  
25 International Business Park  
#04-20/21 German Centre  
Singapore 609916  
Tel +65 6308 9400  
Fax +65 6308 9401  
[asia.pacific@draeger.com](mailto:asia.pacific@draeger.com)

### REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.  
Complejo Business Park,  
V tower, 10th floor  
Panama City  
Tel +507 377 9100  
Fax +507 377 9130  
[contactcsa@draeger.com](mailto:contactcsa@draeger.com)

Locate your Regional  
Sales Representative at:  
[www.draeger.com/contact](http://www.draeger.com/contact)

